



DOUBLE DECKER REPLACEMENT CANOPY Installation Instructions

Video: <https://vimeo.com/966152857>

Questions? 800.919.9464

TOOLS NEEDED



INSTRUCTIONS

Removing the Old Canopy

1 Remove the Upper Deck Canopy

- Ensure the umbrella is standing upright in the base and closed.
- Slide the pockets off the arms of the upper deck canopy.



- Remove the finial by unscrewing the 5/32" bolt holding it in place.



- Take the fabric off to expose the top frame.





DOUBLE DECKER REPLACEMENT CANOPY Installation Instructions

Video: <https://vimeo.com/966152857>

Questions? 800.919.9464

2

Remove the Main Canopy

- While the umbrella is closed, remove the screws holding the canopy to the arms of the frame.
- Allow the canopy to fall or slide off the frame freely.



Installing the New Canopy

3

Open the Umbrella

- Open the umbrella to the lowest pinhole.



4

Attach the Main Canopy

- Spread the new canopy over the frame.



- Place the arms into the individual pockets.





DOUBLE DECKER REPLACEMENT CANOPY Installation Instructions

Video: <https://vimeo.com/966152857>

Questions? 800.919.9464

- Open the umbrella to the highest pinhole.
 - Lay the umbrella on one side.
 - Reattach the screws to secure the canopy to the frame.
-



5

Attach the Upper Deck Canopy

- Raise the umbrella back to a standing position.
 - Close the arms of the umbrella.
 - Place the top canopy over the frame.
-



- Reattach the finial.
-



- Insert the arms of the frame into the pockets of the upper canopy.
 - Open the umbrella to ensure everything is properly attached and functional.
-

